

- If the procedure states the Maximum Interpass Temperature is 350 degrees F and the pipe measures 360 degrees F – What should welder do before starting to weld? (allow joint to cool) What should you do if the welder starts welding at a temperature above the maximum interpass temperature? (document the observation)